




IN-HOUSE PROJECTOR




The projector is permanently mounted centrally above the stage curtain (picture 'A') and is powered via the PA and Lighting control box situated backstage (rear corner). Turn-on the system by switching on the power—the white plug above the control box (see picture 'B').




Point the Remote Control (pictured) towards the Projector and press the red 'power' button.

The Projector will begin to warm-up.




NOTE: The Remote Control also features a Laser pointer to enable you to highlight items of the presentation.



Set-up the Projector Screen in the centre of the stage (picture 'C').

Connect a Laptop or Tablet using the cable that is coiled at the end of the curtain track (L/H side looking from the stage into the Hall - picture 'D').



The cable connection is the industry standard VGA but an assortment of connection adaptors is available (including USB type C & HDMI).

The images from the computer should now be displayed on the projection screen - ***it may be necessary for you to adjust the focus using the chrome ring surrounding the lens (see top picture).***